

Ripper

Mechanical work tool 0-33 tonnes

Break up hard ground and surfaces efficiently

Use the ripper on the excavator to break through hard or frozen ground, remove rocks, tree roots or old pipes. It is an efficient attachment for structural demolition or preparing the ground before using a digging bucket, when conditions are too hard for normal excavation.

The design allows for optimal breakout force and the tooth on the ripper can easily be replaced.



⚙️ Technical specification

Ripper	RP30	RP40	RP45	RP50	RP60	RP70
Bracket	S30	S40	S45	S50	S60	S70
Machine weight [lb]	0-4400	4400-13200	13200-28600	13200-28600	28600-39600	39600-72600
Weight from [lb]	70	167	427	429	612	1210
Length [inch]	19	24.53	35.67	35.67	39.72	49.65